



Piston type  
flow meter

SKM

## Installation and Operating Instructions

### Piston type flow meter

### SKM



Kirchner und Tochter



## Content

1. Foreword.....	3
2. Safety.....	3
2.1. Symbol and meaning.....	3
2.2. General safety directions and exemption from liability.....	3
2.3. Intended use .....	3
2.4. Special safety instructions concerning glass devices.....	4
2.5. Safety information for Operator and operating personnel.....	4
2.6. Regulations and guidelines .....	4
2.7. Notice as required by the hazardous materials directive.....	4
3. Transport and storage.....	4
4. Installation.....	5
4.1. Preparatory work prior to installation.....	5
4.2. Installation SKM.....	6
5. Start-up.....	6
6. Readings in operation.....	7
7. Limit switch RK.....	7
7.1. Connection of limit switches.....	7
7.2. Setting the limit switches.....	8
8. Maintenance.....	8
8.1. Cleaning the device.....	8
8.2. Replacement of measuring glass.....	8
9. Service .....	9
9.1. Disposal.....	9
10. Technical Data .....	10
10.1. Materials.....	10
10.2. Dimensions.....	11
10.3. Technical Data of the limit switches.....	12
10.4. Low-voltage directive.....	12



## 1. Foreword

These Installation and Operating Instructions are applicable to devices of Series SKM. Please follow all instructions and information given for installation, operation, inspection and maintenance. The Instructions form a component part of the device, and should be kept in an appropriate place accessible to the personnel in the vicinity of the location. Where various plant components are operated together, the operating instructions pertaining to the other devices should also be observed.

## 2. Safety

### 2.1. Symbol and meaning



Safety notice

This symbol is placed against all directions/information relating to occupational health and safety in these Installation and Operating Instructions and draws attention to danger to life and limb. Such notices should be strictly observed.

### 2.2. General safety directions and exemption from liability

This document contains basic instructions for the installation, operation, inspection and maintenance of the flow monitor. Failure to comply with these instructions can lead to hazardous situations for man and beast and also to damage to property, for which Kirchner und Tochter disclaims all liability.

The Operator is required to rule out potentially hazardous situations through voltage and released media energy.

### 2.3. Intended use

Series SKM piston-type flow meters are designed for position-independent flow measurement of water, oils and liquids. The flow meters are equipped with a spring-loaded piston that is located in a borosilicate glass cylinder. Together with the spring, the piston with orifice plate hole forms the measuring system. The position of the piston changes according to the flow of medium through the SKM. The position is proportional to the volume flowing through the device. The flow rate can be read directly from the upper edge of the piston against a scale on the glass. The SKM can be installed in horizontal and vertical pipes.

The limit values pertaining to the device are given in Section 10 and should not be exceeded. Modifications or other alterations to the flow meter may only be carried out by Kirchner und Tochter. Details of the process product and the operating conditions are marked on the measuring glass.



## 2.4. Special safety instructions concerning glass devices



For safety reasons, we recommend fitting a protective shield in front of the measuring tube when starting up flow meters fitted with glass measuring tubes. The devices should not be operated where there is a risk of pressure surges (water hammer)!

To avoid glass breakage, all fitting work between measuring glass and heads inside the glass should be carried out by twisting and simultaneously pressing after having wetted the packing rings/gaskets.

## 2.5. Safety information for Operator and operating personnel

Authorized installation, operating, inspection and maintenance personnel should be suitably qualified for the jobs assigned to them and should receive appropriate training and instruction.

## 2.6. Regulations and guidelines

In addition to the directions given in these Installation and Operating Instructions, observe the regulations, guidelines and standards, such as DIN EN, and, for specific applications, the codes of practice issued by DVGW (gas and water) and VdS (underwriters), or the equivalent national codes and applicable national accident prevention regulations.

## 2.7. Notice as required by the hazardous materials directive

In accordance with the law concerning handling of waste (critical waste) and the hazardous materials directive (general duty to protect), we would point out that all flow meters returned to Kirchner und Tochter for repair are required to be free from any and all hazardous substances (alkaline solutions, acids, solvents, etc.).



Make sure that devices are thoroughly rinsed out to neutralize hazardous substances.

## 3. Transport and storage

Always use the original packing for transport, handling and storage. Protect the device against rough handling, impact, jolts, etc.



## 4. Installation

### 4.1. Preparatory work prior to installation

#### Preparation of installation location

- The flow meter can be installed directly behind constrictions.
- To increase the repeat accuracy we recommend a steadying stretch of 5 DN upstream and 3 DN downstream of the appliance. (DN = pipe diameter)
- If necessary, support the ends of the pipeline to prevent vibration from being transmitted to the flow meter.
- Clean by blowing out or flushing the pipes leading to the device before connecting up.
- Prepare the installation point with the appropriate pipe thread before starting to fit the flow meter. Make sure sealing faces are correctly spaced apart and in true alignment.
- On no account should the piston flow meter be used to pull the ends of the pipeline together (stress-free installation!).


#### Preparation of the piston flow meter

- Take the device out of the transport packaging.
- Before installing, remove all protective caps, transport locks and any foreign bodies found.
- Check that the float can move freely in the piston flow meter.
- Have ready appropriate sealing/jointing materials for screw connections. These are not included with the flow meter.
- Check the direction of flow, which should be from the lower to the upper limit of scale. The mounting position of the SKM (vertical, horizontal) is arbitrary.



## 4.2. Installation SKM

The flow meter can be mounted in the installation point after completion of all preparatory work.



Installation: horizontal flow

## 5. Start-up

The device must be properly installed before it is started up.

- Check all device connections.
- To set the flow: pressurize the pipelines by slowly opening the shut-off valves (risk of glass breakage!). On liquid service: carefully evacuate the pipeline.
- Check the leak-tightness of all components and, if necessary, tighten down threaded joints or screw connections.



## 6. Readings in operation

The flow value is read off from the scale on the glass cone at the top edge of the float. The measured-value readings are only correct when the operating condition at the measuring point (flowing medium, operating pressure and temperature) corresponds to the values marked on the measuring glass. If operating conditions should differ, the measured value must be corrected with the aid of the general float equation, which you will find in our technical documents.

## 7. Limit switch RK

The flow meter can be equipped with limit contacts to provide local indication with monitoring function.

The limit switches consist of a limit switch (reed switch) that is switched over by the magnet integrated in the float .

The limit switch is guided in a guide slot in the protective case and can be adjusted over the full measuring range. The reed switches have a bistable characteristic.

Uncontrolled current and voltage peaks can occur in the case of inductive or capacitive loads, e.g. from contactors or solenoid valves. Such peaks will also occur, depending on cable geometry, where cables exceed a certain length.

We therefore recommend using an MSR contact protection relay, which is additionally available.

This will increase the contact rating and prevent occurrence of inductive and capacitive peaks, thus ensuring long service life of the contacts.

Electrical data and limit values are specified in Section 10.

### 7.1. Connection of limit switches



Electrical connection of the device must be carried out in conformity with the relevant VDE regulations (or equivalent national standards) and in accordance with the regulations issued by the local power supply utility.

- Disconnect the plant from supply before connecting the limit switch.
- Provide a protective circuit for the switches in keeping with their capacity.
- Connect line-side fuse elements matched to consumption.
- Connect the cable using the supplied two core PVC cable of 1m length. Assigned are terminals 1 and 2. Earth and terminal 3 are not assigned. The circuit diagram and a drawing of the limit switch are shown in the Technical Data , Section 10.1.



## 7.2. Setting the limit switches

The limit switch is a slot-guided cylinder switch. This is mounted on the back of the flow meter in a slot in the case. The switching point can be changed by sliding the switch along the slot. To do this, detach the M4x6 headless screw on the switch and tighten down after setting the switch position. See drawing in Section 10.1.

## 8. Maintenance


To avoid glass breakage, the device should be inspected at regular intervals, in particular for fouling. If necessary, the device can be cleaned as follows.

### 8.1. Cleaning the device

1. Remove the device from the installation point.
2. Unscrew the M6 headless screws Pos. 1.
3. Remove device heads (Items 2 and 3) and measuring glass (Item 4) from sleeve (Item 9). Take care not to damage the now loose measuring piston (Item 5).
4. Clean all parts and check for signs of wear. Do not use any aggressive cleaning agents (wire brush, scouring agents, alkaline solutions, acids, etc.). When cleaning the device make sure material is not abraded (avoid using emery paper, scrapers or similar).
5. Fit new O-Rings (Pos. 7,8).
6. Mount the SKM in reverse order. Make sure the spring (Item 6) is inserted correctly in the head (Item 2).

### 8.2. Replacement of measuring glass

1. To dismantle the device, proceed as described under Point 8.1.
2. Remove measuring glass and piston, and replace with new ones.  
After mounting the device in the installation location, take note of the directions for start-up given in Section 5.
3. Reassemble the device as described in Section 8.1, steps 5 and 6.





## 9. Service

All devices with defects or deficiencies should be sent direct to our repair department. To enable our customer service facility to deal with complaints and repairs as quickly as possible, you are kindly requested to coordinate the return of devices with our sales department, Tel. +49 2065-96090.

### 9.1. Disposal

Please help to protect our environment, and dispose of workpieces in conformity with current regulations or use them for some other purpose.



## 10. Technical Data

Scale (l/min) measuring range	1:3
Measuring accuracy	4 % FS
Reproducibility	2 % FS
Medium temperature	max +100 °C
Ambient temperature	0 to +50 °C max.
Operating pressure, stat.	PN 10

### 10.1. Materials

Connecting pieces	Nickel-plated brass
Measuring piston	1.4571
Bushing	1.4301
Glass	Borosilicate glass
Gaskets	NBR, optionally EPDM/Viton
Connection	Internal thread acc. ISO 228




SKM

## 10.2. Dimensions


SKM, SKM-RK			
G	A	SW	D
1/4	156	40	48,3
1/2	156	40	48,3
3/4	156	40	48,3
1	156	40	48,3


All dimensions in mm





### 10.3. Technical Data of the limit switches

RK	Design with one contact
Switching voltage	50V AC/75V DC
Switched current	max. 0,2 A
Switching capacity	max. 10 VA, 10 W
Volume resistance	230V AC/DC
Switching performance	bistable
Switching state	LED yellow
Limit value contact	Reedcontact
Temperature range	-25 to +75 °C
Degree of protection	IP 67 (IEC 529)
Switching function	Normally open
	1 —  2



### 10.4. Low-voltage directive

Above 50 V AC/75 V DC, contacts are subject to the EU Low-Voltage Directive.  
The user is required to verify their use accordingly.



The Kirchner equipment has been tested in compliance with the applicable CE-regulations of the European Community. The respective declaration of conformity is available on request.

The KIRCHNER QM-System will be certified in accordance with DIN-EN-ISO 9001:2000. The quality is systematically adapted to the continuously increasing demands. An appropriate declaration of conformity will be provided on request.